

Bi-Parting Swing Gate Installation

Lower Level

9. Assemble rod bracket onto interlock rod and secure with set screws.
10. Slide 2-3/4" spring onto rod bracket and hang linkage bar off spring.
11. Assemble roller arm onto gate post tab and attach linkage bar to roller arm.
12. Attach 4" spring to post and roller arm with 'S' hooks. Position 'S' hooks so that there is slight tension on spring.

* The roller arm should be positioned horizontally with carriage not present.

