Bi-Parting Swing Gate Installation Intermediate Levels Interlock Rod-13. Assemble rod bracket onto interlock LL1573 rod and secure with set screws. Rod Bracket -14. Slide 2-3/4" spring onto rod bracket w/Set Screws. and hang linkage bar off spring. LL1574 15. Assemble roller arm onto gate post tab and attach linkage bar to roller arm. * The roller arm should be positioned at approx. 2 o'clock with carriage not present. Spring LL4230 0 **NOTE:** The roller arm is to Linkage Bar rotate upward when the LL1575 carriage arrives at the floor level (from either direction). Linkage Bar LL1575 Washers Roller Arm Assembly LL3851 Clevis Pin **Shoulder Bolt** 8 HWB12X075SH